

## Replacements for FC front door hinge pins

From DRCORVAIR on Corvair Center Forum

Use Dorman Help! 38400

Drill out to 27/64, add a chamfer for a 0.009" press fit.

Heads of pins are not exact but close enough.

Cut to length and grind taper for OEM look,

Way better fit and durability.

