
988257

UTILITY SIDE RAIL INSTRUCTION SHEET

TRUCK STEPSIDE & FLEETSIDE (EXCEPT 30 SERIES) & CORVAIR 95



STEP 1 CUT RAILS IF REQUIRED. SEE CHART, FIG. 1.

STEP 2 USING DIMENSIONS SHOWN, LOCATE, CENTER PUNCH & DRILL FORWARD ATTACHING HOLE FOR EACH SUPPORT, SEE FIG. 1.

\$7EP 3 WITH SUPPORT CENTERED, USE AS A TEMPLATE TO LOCATE & DRILL REMAINING HOLES. SEE FIG. 1.

STEP 4 INSTALL ALL SUPPORTS & RAILS LOOSELY WITH SCREWS. ALIGN RAIL & SUPPORT & PROGRESSIVELY TIGHTEN ALL SCREWS SECURELY, SEE FIG. 1.

STEP 5 INSTALL ENDS WITH ATTACHING SET SCREWS. SEE VIEW A.

STEP 6 REPEAT STEPS FOR OPPOSITE SIDE.