

GREENBRIER TAXI- CAB EQUIPMENT - RPO 420

MODEL APPLICATION R1206



INTERIOR TRIM

Standard ----- All vinyl, silver

FLOORS, Front and Rear

Covering ----- Waterproof asphalt impregnated paper felt, .125 minimum thickness. (Driver compartment)

Mats ----- Charcoal colored vinyl coated rubber (Passenger compartment)

SEATS ----- Passenger seat to face forward and to be located in the forward position.

INSTRUMENT PANEL

Warning Lamp

Location ----- Bright metal bracket under instrument panel, left of steering column.

Switch ----- Forward door in passenger compartment on R.H. side of standard models, and by both R.H. and L.H. forward doors when optional L.H. doors are used.

Spare Tire Cover ----- Color keyed fabric



Front Shock Absorbers ----- Heavy duty

Lubrication fittings ----- Used at "U" Joints of Propellor shaft

Battery ----- Heavy duty