

LAMP—GLOVE COMPARTMENT
985898
ALL PASSENGER CARS AND TRUCKS




FIG. 1 CHEVROLET




FIG. 2 (PASS "A")

CHEVROLET & PASS "A"

STEP 1 ROUTE WIRE TERMINAL THRU NOTCH IN UPPER LEFT HAND CORNER OF INSTRUMENT PANEL COMPARTMENT & THRU HOLE IN UPPER LEFT SIDE OF COMPARTMENT OPENING. SEE FIG. 1 & 2.

STEP 2 ASSEMBLE WIRE TERMINAL TO SWITCH. INSERT LAMP & PRESS SWITCH INTO POSITION. SEE VIEW A.

STEP 3 (CHEVROLET) ROUTE WIRE ALONG EXISTING HARNESS & THRU EXISTING RETAINER TO FUSE PANEL. TAPE WIRE TO HARNESS AS SHOWN. SEE FIG. 1.

STEP 4 (CHEVROLET) PLUG WIRE CONNECTOR INTO

RECEPTACLE MARKED "BATT." SEE FIG. 1.
NOTE If receptacle is occupied, remove existing wire & connect to jumper wire. Discard Clip & Blade Asm. & Fuse.

STEP 5 (PASS "A") ROUTE WIRE DOWN TO REINFORCEMENT & ATTACH WIRE WITH PROVIDED CLIP. ROUTE WIRE ALONG EXISTING HARNESS TO FUSE PANEL. TAPE WIRE TO HARNESS AS SHOWN. SEE FIG. 2.

STEP 6 (PASS "A") PLUG WIRE CONNECTOR INTO RECEPTACLE MARKED "BAT. FUSED". SEE FIG. 2. **NOTE** If receptacle is occupied, remove existing wire & connect to jumper wire. Discard Clip & Blade Asm. & Fuse.




FIG. 3 CORVAIR

CORVAIR

STEP 1 ROUTE WIRE TERMINAL THRU SLIT IN UPPER LEFT HAND CORNER OF INSTRUMENT PANEL COMPARTMENT & THRU HOLE IN UPPER LEFT SIDE OF COMPARTMENT OPENING. SEE FIG. 3 & VIEW C.



STEP 2 ASSEMBLE WIRE TERMINAL TO SWITCH. INSERT LAMP & PRESS SWITCH INTO POSITION. SEE VIEW C.

STEP 3 ROUTE WIRE THRU EXISTING CLIPS (ON DASH) TO

FUSE PANEL. SEE FIG. 3.

STEP 4 PRESS CLIP & BLADE INTO RECEPTACLE MARKED "GL. BOX LP.", INSERT FUSE & CONNECT WIRE. SEE VIEW B. **NOTE** If receptacle is occupied, remove existing wire & connect to jumper wire. Discard clip & blade asm. & fuse.

STEP 5 LOOP & TAPE EXCESS WIRE. SEE FIG. 3.
NOTE Discard remaining parts.



TRUCK R-10 & TRUCK

STEP 1 ROUTE WIRE TERMINAL THRU SLIT IN UPPER LEFT HAND CORNER OF INSTRUMENT PANEL COMPARTMENT & THRU HOLE IN UPPER LEFT SIDE OF COMPARTMENT OPENING. SEE FIG. 4 OR 5 & VIEW C, FIG. 3.

STEP 2 ASSEMBLE WIRE TERMINAL TO SWITCH, INSERT LAMP & PRESS SWITCH INTO POSITION, SEE FIG. 4 OR 5 & VIEW C, FIG. 3.

STEP 3 (TRUCK R-10) ROUTE WIRE TO FUSE PANEL BY LOOPING AROUND R. H. DEFROSTER DUCT, PASS OVER L. H. DEFROSTER DUCT, LOOP AROUND EXISTING WIRING HARNESS ALONGSIDE OF EXISTING CLIP. SEE FIG. 5.

STEP 4 (TRUCK) MOUNT CLIPS ON FORWARD FLANGE OF INSTRUMENT PANEL REINFORCEMENT & ROUTE WIRE THRU THESE CLIPS TO FUSE PANEL. SEE FIG. 4 & VIEW D.

STEP 5 PRESS CLIP & BLADE INTO RECEPTACLE MARKED "GL BOX LP." INSERT FUSE & CONNECT WIRE. SEE VIEW B & FIG. 3. **NOTE** If receptacle is occupied, remove existing wire & connect to jumper wire.

STEP 6 LOOP & TAPE EXCESS WIRE. SEE FIG. 4 OR 5.
NOTE Discard remaining parts.